THUNDERBOOK
RUGGED FOR LIFE

QUICK USER'S GUIDE

COLOSSUS A800

TABLE OF CONTENTS

EN

Safety Instructions.....4

Package Contents.....8

Device Description.....9

Inserting SIM y Micro-SD Cards.....12

Use of the barcode reader.....14

SAFETY INSTRUCTIONS

Warning: Please read and observe carefully before using the device!

Batteries:

Batteries are parts whose life cycle depends on handling. If no failure is reported within 3 months after receipt of the equipment, the battery will be considered to be functioning properly. Failure to comply with these regulations will lead to the loss of guarantee.

Please note the following:

- Fully charge the battery every three months.
- Do not work with the device at less than 20% battery as it may damage the battery. The device will not come under warranty if it is detected that the battery is at 0% charge.
- The LED indicator on the front of the tablet should blink during charging. If not, it is due to a battery failure.
- Before working in negative temperatures, make sure the battery is 85% charged or higher.
- In negative temperatures do not work with the equipment with a load below 60%.
- The battery charge temperature is 0ºC to 40ºC.
- The storage temperature of the battery is between 0ºC and 25ºC. Charge the battery (or equipment) before storing it.
- Avoid exposing the device or battery to high temperatures.
- Do not overcharge the battery. The full charge is indicated when the indicator LED stops flashing.

- Do not expose the battery to mechanical stress.
- Do not damage the batteries with sharp or pointed objects.
- Do not throw batteries into fire - they may explode.
- Do not throw liquids on the batteries.
- Avoid short-circuiting the batteries, as it can lead to overheating and ignition of the battery.
- If liquid comes out of the battery and comes into contact with eyes or skin, rinse immediately with clean water and seek medical attention.
- Incorrect battery replacement may cause a risk of explosion.
- Replace the battery only with the same or equivalent recommended by the manufacturer.
- Batteries should not be disposed of with normal household waste. Use the service of specialized stores that perform recycling.

SAFETY INSTRUCTIONS

Environment:

Protect the device from temperatures outside the specified range. The device is protected against spray water but must not be submerged in water or be exposed to water jets. Do not expose the unit to strong magnetic fields or strong static electricity. Once water or liquid has entered the unit, turn it off and do not use until it is dried. Have it checked by a qualified specialist.

Safety in operation:

Do not drop the device. Do not bend or twist it. This may result in a breakage of the display glass or of circuit boards and mechanical parts. To avoid hearing damage, listen to music via headphones at a moderate volume and never place the speaker outputs directly in front of your ear. Keep packaging materials and small parts away from children. There is a danger of suffocation. Never open the case of the appliance or the charger (risk ofelectric shock, short-circuit and fire). Do not put objects through slots or openings on the appliance or charger (risk of electric shock, short circuit, and fire). Do not attempt to open the unit, the unit may be destroyed and you will lose warranty.

Cleaning:

Never clean the surface of the appliance with solvents, detergents or other chemical products. Use a soft, dry cloth instead.

Power supply:

Always use the original charger or one with suitable current and voltage rating to prevent damage to the device. If you use an universal charger, consider the polarity of the charger as well as the current and the voltage rating. Do not unplug the charger from the wall outlet by pulling the cable. Do not use chargers with damaged cables or plugs.

Disposal:

Dispose used electronic equipment at the appropriate collection points. Please note that your device has a battery and therefore it must not be disposed with normal household waste. Please consult your local or municipal authorities for the correct disposal route of your device and battery.

PACKAGE CONTENTS

Check your product box for the following items:

- Colossus A800
- Hand Strap
- Micro-USB to female USB cord (15cm)
- Micro-USB to male USB cord (1m)
- DC-Jack Charger
- USB Charger
- Carrying Bag

CE

This device is in compliance with the essential safety requirements and other relevant provisions set out in the European Directive.

DEVICE DESCRIPTION


EN

① Barcode Scanner Trigger
② Power
③ Volume +
④ Volume -
⑤ Barcode Scanner (optional)
⑥ Touchscreen
⑦ Camera
⑧ Status LED



DEVICE DESCRIPTION

9 Kensington Lock
10 Audio
11 Micro HDMI Port
12 Micro-USB Port
13 USB Port
14 DC-In
15 SD card
16 SIM card



17 Camera

18 Hand Strap Fixation Ponts

19 RFID Area

20 Vehicle Dock Fixation Points



INSERTING SIM & MICRO-SD CARDS

Warning:
To install or to remove the SIM card or SD card, the device has to be switched off first.


Opening
Pull to open the rubber cover. Opening is hard to ensure the IP sealing.

Inserting the mini SIM card
The slot accepts only mini SIM cards. Insert the card into the SIM slots like shown in the picture on the next page.

Inserting a SD card
Insert the micro SD card like show in the picture on the next page.

Closing
Close the rubber cover back to ensure the sealing of the device.

Tip:
For the SIM card, a Pin number may be requested. Enter the SIM card pin number and tap OK.


micro SD
MINI SIM

USE OF THE BARCODE READER

Attention:

- To **activate the reader** it is necessary to start the "application" **HardDeCode** if the device has been rebooted, shut down or restored.
- Your device may not have a barcode reader, depending on the configuration acquired.
- Note that the default configuration of the reader is via USB HID.



Use barcode reader

1. Make sure there is an application open on the device and that a text field is focused (with the text cursor in the text field).
2. Point to a barcode with the top of the device.
3. Press and hold the shutter button (located on the top of the device with the letter "F").
4. The data capture LED is lit and a beep sounds by default to indicate that the barcode has been decoded correctly. Focus the capture LED on the barcode until the beep sounds.
5. Release the trace button. Barcode content data is displayed in the text field.

Location of the trigger button + barcode reader



Av. Corts Catalanes, 5-7
08173 - Sant Cugat del Valles
Barcelona - Spain
https://www.thunderbook.eu