QUICKGUIDE

Nordic ID **RF601**
Nordic ID **RF651**

NORDICID

GETTING STARTED

This document describes how to take the RF601/RF651 into use.

RF601/RF651 PACKAGE CONTENTS

- Handheld terminal
- Two batteries

THE MAIN STEPS ARE:

- Installing batteries
- Using the device


INSTALLING BATTERIES

The batteries comes pre-installed in the unit's battery compartment. Turn the unit over and remove the protective plastic strip from the battery compartment.


If you need to replace the batteries for any reason, please follow the instructions to the right for installing the batteries:

If using rechargeable batteries, use only batteries supplied by Nordic ID.


1



2




SCANNING DIRECTION



LASER LIGHT!
DO NOT STARE INTO BEAM!
CLASS 2 LASER!

KEYBOARD



- Scan key
- OK key
- Up / down movement key
- Function keys (F1-F5)
- Alpha / numeric keys
- Delete key
- Steadily lit: Battery charging
  Blinking: Battery full

- Shift — Alpha / numeric mode
- Shift + DEL — Reset
- Shift + 0 — Settings menu
- Shift + OK — Keyboard lock
- Shift + • — Light / scanner (only RF651)
- Shift + 1 — BT Power saving mode (only RF651)

NORDIC ID

Myllyojankatu 2 A
24100 SALO, FINLAND
tel. +358 2 727 7700
fax +358 2 727 7720
www.nordicid.com
service@nordicid.com

http://extranet.nordicid.com/



HEADQUARTERS
support@nordicid.com
phone: +358 2 7277 790

DEUTSCHSPRACHIGE LÄNDER
support@nordicid.de
Tel: +49 521/557717-0



Limited warranty: 2 years

Repair centers
www.nordicid.com/eng/support

V1002

NORDIC ID RF601

NORDIC ID RF651