
NX-7510/NX-7520/NX-7530 Series
Integrated Services Platform
Disk Drive Assembly Replacement Instructions

Description	Part Number
NX 7500 HDD FRU	NX-7500-HD-500GB

Replacing a Disk Drive Assembly

Confirm that you have the appropriate replacement disc drive assembly before beginning the installation procedure.
To replace a disk drive:

1. Power down the services platform.
2. Press the release button on the right side of the drive assembly to release the assembly lock.
3. Pull the drive handle lever to the left to remove the drive assembly from the drive bay as shown below.



4. Insert the new drive assembly in the drive bay.
5. Push the drive assembly into the drive bay until the lever locks into place.
6. Apply power by pressing the power button located on the front of the services platform.

MN001695A01 Revision A April 2015